

Vintec

V20SG e

POWER

LIGHT

RUN

8.8 °C
DISPLAY

UP

DOWN

User Manual

V20BVCBK



Important information that may impact your Manufacturer's Warranty

Adherence to the directions for use in this manual is extremely important for health and safety. Failure to strictly adhere to the requirements in this manual may result in personal injury, property damage and affect your ability to make a claim under the Vintec manufacturer's warranty provided with your product. Products must be used, installed and operated in accordance with this manual. You may not be able to claim on the Vintec manufacturer's warranty in the event that your product fault is due to failure to adhere this manual.

WARNING

The information in this document is subject to modification without any prior notice.

Somes models are available in dedicated countries only.

VINTEC offers no guarantee for our Beverage Center if it is being used for any purpose other than that for which it was specifically designed. **VINTEC** cannot be held responsible for any error in this manual. **VINTEC** is not responsible or liable for any spoilage or damage to beverage or any other contents incidental or consequential to possible defects of the Beverage Center. Warranty applies to the Beverage Center only and not to the content of the Beverage Center.

This appliance is not intended for use by persons (including children) with reduced physical, sensory or mental capabilities, or lack of experience and knowledge, unless they have been given supervision or instruction concerning use of the appliance by a person responsible for their safety.

Children should be supervised to ensure that they do not play with the appliance.

R600A WARNINGS

The following models use small quantity of R600A (iso-butane) flammable refrigerant:

V20BVC – 25g S3/BK

For your safety please observe the following recommendations :

- This appliance contains a small quantity of R600A refrigerant which is environmentally friendly, but flammable. It does not damage the ozone layer, nor does it increase the greenhouse effect.
- During transportation and installation, ensure that the tubing of the refrigerant circuit is not damaged.
- Avoid using or manipulating sharp objects near by the appliances.
- Leaking refrigerant can ignite and may damage the eyes.
- In the event any damage does occur, avoid exposure to open fires and any device that creates a spark. Disconnect the appliance from the mains power.
- Thoroughly ventilate the room in which the appliance is located for several minutes.
- Notify Customer Service for necessary action and advice.

- The room for installing the appliance must be at least 1 cubic metre per 8 grams of refrigerant. The refrigerant quantity contained in this appliance is listed above in grams; it is also noted on the Rating Plate of the appliance.

It is hazardous for anyone other than an Authorised Service Person to carry out servicing or repairs to this appliance.

- WARNING: Keep ventilation openings in the appliance enclosure or in the built-in structure clear of obstruction.
- WARNING: Do not use mechanical devices or other means to accelerate the defrosting process, other than those recommended by the manufacturer.
- WARNING: Do not damage the refrigerant circuit.
- WARNING: Do not use electrical appliances inside compartments of the appliance.
- WARNING: In Queensland Australia the authorized person must hold a Gas Work Authorisation for hydrocarbon refrigerants, before carrying out servicing or repairs which involve the removal of covers.

The environment and personal safety must be considered when disposing of this appliance. Please ensure the appliance is taken to a recycle center for safe recycling. DO NOT dispose of the appliance in land fill as the insulation and refrigerant gas contained in these appliances are flammable.

Allow 24 hours before switching on the Beverage Center. During this time we recommend that you leave the door open to clear any residual odors.

BEFORE LOADING & PLUGGING IN THE BEVERAGE CENTER

Important: All models without front venting (air opening) are strictly for free standing only. (see technical chart)

Recommendations:

The location you have selected for your Beverage Center should:

- be unencumbered and well ventilated;
- be well away from any heat source and direct sunlight;
- not be too damp (laundry, pantry, bathroom etc.);
- have a flat floor;
- have a standard and reliable electricity supply (standard socket to country standards, linked to the ground), it is NOT recommended to use a multi-socket or extension lead.
- have a surge protector fitted to the electrical outlet;
- away from the microwave oven. Certain microwave ovens do not have wave interference shield. When placed within 1 meter vicinity of the Beverage Center, they may affect the operation of the Beverage Center.

The Beverage Center should be placed where the ambient temperature is between 5°C to 35°C. If the ambient temperature is above or below this range, the performance of the unit may be affected. Placing your unit in extreme cold or hot conditions may cause interior temperatures to fluctuate. The ideal range of temperature may not be reached. (See Climate Class at the end of this manual)

Grounding instructions

The Beverage Center must be grounded in case of an electrical short circuit. Grounding reduces the risk of electrical shock. The Beverage Center is equipped with a power cord having a grounding wire and plug. The Beverage Center plug must be plugged into a properly affixed and grounded electrical outlet.

Note: *In locations where there is frequent lightning, surge protectors **MUST** be used.*

Improper use of the grounding plug can result in the risk of electric shock. Consult a qualified electrician or service person if the grounding instructions are not completely understood.

If the supply cord is damaged, it must be replaced by a qualified person in order to avoid electrical hazard.

Installing your Beverage Center

Unpack and remove all of the protection and adhesive strips from the packaging around and inside the Beverage Center.

The Beverage Center must be positioned such that the plug is accessible. Release the power cord. Move your Beverage Center to its final location. The Beverage Center should be installed in a suitable place where the compressor will not be subject to physical contact. This center cannot be integrated behind a solid door – doing so voids the warranty.


Leveling your Beverage Center: Beverage Center must be leveled BEFORE loading your beverages.

Your Vintec Beverage Center is equipped with 4 adjustable feet to facilitate easy leveling. VINTEC recommends that you screw the back feet toward the base so they are in the shortest position and adjust the front feet to level the Beverage Center.

Back spacer:

Compressor run appliances require proper ventilation for proper and longer usage. Your Vintec Beverage Center is supplied with a back spacer. Affix the back spacer at the back of air circulation and heat evacuation.

INSTALLATION OF BACK SPACER



IMPORTANT - THIS SPACER MUST BE ATTACHED TO THE UNIT BEFORE INSTALLATION FOR VENTILATION PURPOSE. FAILURE TO DO SO VOIDS THE WARRANTY

TURNING ON YOUR BEVERAGE CENTER

Plug in and switch on the unit by pressing on the power button **for a few seconds**.

When you use the Beverage Center for the first time (or restart the Beverage Center after having it shut off for a long time), there will be a few degrees, variance between the temperature you have selected and the one indicated on the LED readout. This is normal and it is due to the length of the activation time. Once the Beverage Center is running for a few hours everything will stabilize.

Important: If the unit is unplugged, power is lost, or turned off, wait 5 minutes before restarting the unit. The Beverage Center will not start if you attempt to restart before this time delay.

Operating Noises

To reach the desired temperature settings, VINTEC Beverage Center, like all Beverage Centers operating with compressors and fans, may produce the following types of noises. These noises are normal and may occur as follows:

- Gurgling sound - caused by the refrigerant flowing through the appliance's coils.
- Cracking/popping sounds -resulting from the contraction and expansion of the refrigerant gas to produce cold.
- Fan operating sound - to circulate the air within the Beverage Center.

An individual's perception of noise is directly linked to the environment in which the Beverage Center is located, as well the specific type of models. VINTEC Beverage Centers are in line with international standards for such appliances. VINTEC will always do its utmost to satisfy its customers but will not retake possession of the goods due to complaints based on normal operating noise occurrences.

LOADING YOUR BEVERAGE CENTER

You may load your beverage bottles in single or double rows while taking note of the following: if you do not have enough bottles to fill your Beverage Center, it is better to distribute the load throughout the Beverage Center so as to avoid "all on top" or "all below" type loads.

- Do remove or relocate adjustable shelves to accommodate larger type of bottles or increase the capacity of the cellar by stacking the bottles up when necessary. (See removing shelves)
- Keep small gaps between the walls and the bottles to allow air circulation. As in an underground cellar, air circulation is important to prevent mould and for a better homogeneous temperature within the cellar.



- Do not over load your Beverage Center to facilitate air circulation.
- Avoid obstructing the internal fans (located inside on the back panel of the Beverage Center).
- Do not slide the shelves outwards beyond the fixed position in order to prevent the bottles from falling.
- Do not pull out more than one loaded shelf at a time as this may cause the Beverage Center to tilt forward.
- Do not cover the shelves with alloy foil or other materials, as it will obstruct air circulation.
- Do not move your Beverage Center while it is loaded with beverages. This might distort the body of the Beverage Center and cause back injury.

TYPES OF REGULATION

Please note that, depending on the loading and settings chosen, it takes about 24 hours for the Beverage Center to see the temperature stabilizing.

During this time LED seems to move erratically. It is normal and this process occurs whenever the setting is modified and/or whenever a large amount of bottles are added to the unit.

TEMPERATURE SETTINGS


Important: The LCD displays, by default, the actual internal air temperature.

The temperature settings are pre-set at the factory setting of 5 °C. In the event of a power interruption, all previous temperature settings are automatically erased and it will revert to the preset temperature settings.

It is important to understand that there is a difference between the air temperature inside the Beverage Center and the actual temperature of the Beverage: You will need to wait approximately 12 hours before noticing the effects of temperature adjustment due to the critical mass within a full Beverage Center.

Once the temperature is set, it is strongly advised not to toy with it or adjust frequently. The thermostat will maintain the temperature inside the Beverage Center within a +/- 2.5°C range. But the thermal inertia of the beverages and the glass is such that, within this temperature range, the actual temperature of the Beverage will only fluctuate 0.5°C to 1°C.

The controls of your beverage center



Adjust the desired cooling temperature by pressing the UP or DOWN buttons. Each depression of the button will scroll through the available temperature settings in increments of 1 degree Celsius. The temperature setting can be adjusted from 2° to 10°. To visualize the “set” temperature, press and hold the UP or DOWN buttons, the “set” temperature will temporarily “flash” in the LED display for 5 seconds.

Internal light

In order to reduce energy consumption, this wine cabinet will automatically switch off the LED lights after 10 minutes.

If you want the LED light to remain on continuously, this is possible. Please press and hold the "LIGHT" button for 5 seconds, the display will show "LP". After 4 seconds the display will revert back to normal and the light will remain on until manually switched off. If you want to revert back and conserve energy (recommended), please press and hold the "LIGHT" button for 5 seconds, the display will show "LF", after 4 seconds the display will revert back to normal, and the light will automatically switch off after 10 minutes.

DEFROSTING/CONDENSATION/ HYGROMETRY/ VENTILATION

Your beverage center is designed with “Auto-cycle” defrost system. During “Off-cycle” the refrigerated surfaces of the beverage center defrost automatically. Defrost water from the beverage center storage compartment drains automatically and part of it goes into a drainage container, which is located at the back of the beverage center next to the compressor. The heat is transferred from the compressor and evaporates any condensation that has collected in the pan. Part of the remaining water is collected within the beverage center for humidity purposes.

This system enables the creation of the correct humidity level inside your beverage center required by the natural cork to maintain a long lasting seal.

Notes: *The water collected by condensation, is therefore recycled. Under extremely dry environmental conditions, you may have to add some water into the water container provided with your beverage center.*

All units are equipped with a double glazed glass door that has a third internal acrylic layer to minimize condensation on the glass door.


The beverage center is not totally sealed; fresh air admission is permitted through the drainpipe. Air is circulated through the unit by means of a fan/fans and the slatted shelves.

Notes: *During the refrigerating cycle, heat is given off and disperses through the external surfaces of the beverage center. Avoid touching the surfaces during those cycles.*

ADJUSTABLE SHELVES

Adjusting/removing the shelves

When removing any of these shelves out of the rail compartment - to fit or remove the shelf - tilt the shelf as per the diagram and simply pull out, or push in the shelf until it sits on the support brackets securely.




REVERSIBILITY OF THE DOOR

Warning: To avoid accidents during the process of changing the door, we recommend that you get assistance. The glass door is heavy and may cause injury if dropped.

- Depending on the model and the type of handle your wine cabinet is equipped with, you may have to rotate the door through 180 degrees.
- Depending on the type of handle your wine cabinet is equipped with, the door may not be reversible or may require that a left or right opening door be ordered to change the opening side.

V20BVCBK




1 Lock screws	2 Lower hinge (Right)	3 Door axis
4 Top hinge (Right)	5 Door	6 Cabinet body
7 Top hinge (Left)	8 Lower hinge (Left)	

- Unscrew the lock screws (1); (Fig. 1) to remove the door axis located at the bottom.
- **While holding the door firmly**, pull the door (5) outward and take it out; (Fig. 2)
- Remove the 3 bolts and take out the right top hinge (2); (Fig. 3)
- Fix the left top hinge and the bottom left hinge with the bolts as per Fig. 4,
- Re-install the door the same way it was removed and fix back the door axis.


4. To provide good performance this cabinet requires adequate ventilation. The Vintec Beverage Center cabinet requires 10mm clearance on both sides, on top; and 30mm clearance at the rear. (You must fit the back spacer provided, it will ensure the minimum 30mm clearance at the rear). A ventilation grid needs to be installed in this 30mm clearance area at the rear. For good ventilation, it is necessary to install a grill with a minimum size of 200x40mm at the top of the back wall or on either side at the top rear – refer to diagrams on the following pages. This is to allow cooler fresh air to flow into the 30mm gap at the rear of the cabinet. The ventilation grill must not be installed close to an oven or next to a sealed area without access to fresh cool air. (Do call Vintec's Service Department for further explanation. Failure to comply with the above specifications could void the WARRANTY.)

VENT SPECIFICATIONS

Front View



Cross section



5. This Vintec Beverage Center is front venting. The cabinet draws air from the front and rear and expels through the grill under the door at the front. If a joinery kick board is being placed in front of the Beverage Center, a grill of at least the same width as the Beverage Center grill and with a minimum airflow allowance of 150cm² must be installed into the kick board.
6. This unit has a power switch located on the control panel. Power point location is therefore not critical.
7. This unit requires a standard 240 volt/10 amp power point.
8. The power cord is 1.9m in length and is affixed to the right side at the back of the cabinet.
9. As with most appliances of today, this cabinet has sensitive electronic components which are susceptible to damage by lightning and electricity supply faults. It is therefore advisable to use a power surge protector to avoid problems of this nature.
10. Please see detailed dimensional diagrams in the preceding pages. Please note: The preceding diagram is for the 85mm plinth recess models.

Further Instructions:

The location you have selected for your Beverage Centre should:


- be unencumbered and well ventilated;
- be well away from any heat source and direct sunlight;
- not be too damp (laundry, pantry, bathroom etc.);
- have a flat floor;
- have a standard and reliable electricity supply (standard socket to country standards, linked to the ground). It is NOT recommended to use a multi-socket or extension lead;
- have a surge protector fitted to the electrical outlet;
- be away from the microwave;

Note: Certain microwave ovens do not have wave interference shield. When placed within a 1 meter vicinity of the Beverage Center, they may affect the operation of the wine cabinet.


- do not cover the glass door with any other kind of door - this unit CANNOT be integrated behind joinery

Notes: Not complying with any of the above instructions may result in WARRANTY void.


Dimensional drawings:



FRONT VIEW



SIDE VIEW



TOP VIEW

NOTE: Illustrations not to scale.
All dimensions in millimetres.

* Minimum 10mm required whether proud-fit or flush-fit, however 30mm is recommended on the opening edge for easy finger grip access when installed flush-fit.

OPERATION ANOMALIES

Ensure that there is power to the electrical supply plug by connecting another electrical appliance to it. Check fuse, if any. Make sure that the door is closed properly.

If your beverage center appears to be malfunctioning, unplug it and contact your VINTEC's after sales service. Any intervention on the cold circuit should be performed by a refrigeration technician who should carry out an inspection of the circuit sealing system. Similarly, any intervention on the electrical circuit should be performed by a qualified electrician.

Notes: *Any intervention performed by a non authorized technicians by Vintec will lead to the warranty being considered as null and void.*

POWER FAILURES

In the event of a power interruption, all previous temperature settings are automatically erased and it will revert to a preset temperature setting .

Most power failures are corrected within a short period of time. An hour or two's loss of power will not affect your beverage center temperatures. To avoid sudden change of temperature while the power is off, you should avoid opening the door. For longer period of power failure, do take steps to protect your beverage.

Irrespective of the cause, if you notice either abnormal temperature or humidity levels inside your beverage center, be reassured that only long and frequent exposure to these abnormal conditions can cause a detrimental effect on your beverage.

TROUBLESHOOTING GUIDE

Common problems may easily be solved, saving you the cost of a possible service call. Please read carefully the instruction manual and revert to troubleshooting guide chart.

PROBLEM	POSSIBLE CAUSE
Beverage center does not operate.	Not plugged in. The appliance is turned off. The circuit breaker tripped or the fuse is broken.
Beverage center is not cold enough.	Check the temperature control setting. External environment may require a higher setting. The door is opened too often. The door is not closed completely. The door gasket does not seal properly.
Turns on and off frequently.	The room temperature is hotter than normal. A large amount of contents has been added to the Beverage center. The door is opened too often. The door is not closed completely. The temperature control is not set correctly. The door gasket does not seal properly.
The light does not work.	Not plugged in. The circuit breaker tripped or a blown fuse. The light is out of order. The light button is "OFF".
Vibrations.	Check to assure that the Beverage Center is level.
The Beverage center seems to make too much noise.	The rattling noise may come from the flow of the refrigerant, which is normal. As each cycle ends, you may hear gurgling sounds caused by the flow of refrigerant in your Beverage center. Contraction and expansion of the inside walls may cause popping and crackling noises. The Beverage Center is not level.
The door will not close properly.	The Beverage Center is not level. The door was reversed and not properly installed. The gasket is faulty. (magnet or rubber is spoiled) The shelves are out of position.



FOR SALES IN AUSTRALIA AND NEW ZEALAND
APPLIANCE: ALL VINTEC/TRANSTHERM

This document sets out the terms and conditions of the product warranties for Vintec/Transtherm Appliances. It is an important document. Please keep it with your proof of purchase documents in a safe place for future reference should there be a manufacturing defect in your Appliance. This warranty is in addition to other rights you may have under the Australian Consumer Law.

1. In this warranty:

- (a) 'ACL' or 'Australian Consumer Law' means Schedule 2 to the Competition and Consumer Act 2010;
- (b) 'Appliance' means any Electrolux product purchased by you and accompanied by this document;
- (c) 'ASC' means Electrolux's authorised serviced centres;
- (d) 'Vintec/Transtherm' is the brand controlled by Electrolux Home Products Pty Ltd of 163 O'Riordan Street, Mascot NSW 2020, ABN 51 004 762 341 in respect of Appliances purchased in Australia and Electrolux (NZ) Limited (collectively "Electrolux") of 3-5 Niall Burgess Road, Mount Wellington, in respect of Appliances purchased in New Zealand;
- (e) 'Warranty Period' means the period specified in clause 3 of this warranty;
- (f) 'you' means the purchaser of the Appliance not having purchased the Appliance for re-sale, and 'your' has a corresponding meaning.

2. Application: This warranty only applies to new Appliances, purchased and used in Australia or New Zealand and is in addition to (and does not exclude, restrict, or modify in any way) other rights and remedies under a law to which the Appliances or services relate, including any non-excludable statutory guarantees in Australia and New Zealand.

3. Warranty Period: Subject to these terms and conditions, this warranty continues for in Australia for a period of 24 months and in New Zealand for a period of 24 months, following the date of original purchase of the Appliance.

4. Repair or replace warranty: During the Warranty Period, Electrolux or its ASC will, at no extra charge if your Appliance is readily accessible for service, without special equipment and subject to these terms and conditions, repair or replace any parts which it considers to be defective. Electrolux may, in its absolute discretion, choose whether the remedy offered for a valid warranty claim is repair or replacement. Electrolux or its ASC may use refurbished parts to repair your Appliance. You agree that any replaced Appliances or parts become the property of Electrolux.

5. Travel and transportation costs: Subject to clause 7, Electrolux will bear the reasonable cost of transportation, travel and delivery of the Appliance to and from Electrolux or its ASC. Travel and transportation will be arranged by Electrolux as part of any valid warranty claim.

6. Proof of purchase is required before you can make a claim under this warranty.

7. Exclusions: You may not make a claim under this warranty unless the defect claimed is due to faulty or defective parts or workmanship. This warranty does not cover:

- (a) light globes, batteries, filters or similar perishable parts;
- (b) parts and Appliances not supplied by Electrolux;

- (c) cosmetic damage which does not affect the operation of the Appliance;
- (d) damage to the Appliance caused by:
 - (i) negligence or accident;
 - (ii) misuse or abuse, including failure to properly maintain or service;
 - (iii) improper, negligent or faulty servicing or repair works done by anyone other than an Electrolux authorised repairer or ASC;
 - (iv) normal wear and tear;
 - (v) power surges, electrical storm damage or incorrect power supply;
 - (vi) incomplete or improper installation;
 - (vii) incorrect, improper or inappropriate operation;
 - (viii) insect or vermin infestation;
 - (ix) failure to comply with any additional instructions supplied with the Appliance;

In addition, Electrolux is not liable under this warranty if:

- (a) the Appliance has been, or Electrolux reasonably believes that the Appliance has been, used for purposes other than those for which the Appliance was intended, including where the Appliance has been used for any non-domestic purpose;
- (b) the Appliance is modified without authority from Electrolux in writing;
- (c) the Appliance's serial number or warranty seal has been removed or defaced.

8. How to claim under this warranty: To enquire about claiming under this warranty, please follow these steps:

- (a) carefully check the operating instructions, user manual and the terms of this warranty;
- (b) have the model and serial number of the Appliance available;
- (c) have the proof of purchase (e.g. an invoice) available;
- (d) telephone the numbers shown below.

9. Australia: For Appliances and services provided by Electrolux in Australia: Electrolux goods come with guarantees that cannot be excluded under the Australian Consumer Law. You are entitled to a replacement or refund for a major failure and for compensation for any other reasonably foreseeable loss or damage. You are also entitled to have the Appliance repaired or replaced if the Appliance fails to be of acceptable quality and the failure does not amount to a major failure. 'Acceptable quality' and 'major failure' have the same meaning as referred to in the ACL.

10. New Zealand: For Appliances and services provided by Electrolux in New Zealand, the Appliances come with a guarantee by Electrolux pursuant to the provisions of the Consumer Guarantees Act, the Sale of Goods Act and the Fair Trading Act. Where the Appliance was purchased in New Zealand for commercial purposes the Consumer Guarantee Act does not apply.

11. Confidentiality: You accept that if you make a warranty claim, Electrolux and its agents including ASC may exchange information in relation to you to enable Electrolux to meet its obligations under this warranty.

Important Notice

Before calling for service, please ensure that the steps listed in clause 8 above have been followed.

FOR SERVICE or to find the address of your nearest authorised service centre in Australia PLEASE CALL 1800 771 776 <small>For the cost of a local call (Australia only)</small>	AUSTRALIA ELECTROLUX HOME PRODUCTS 163 O'Riordan Street, Mascot NSW 2020 vintec.com.au	FOR ACCESSORIES PLEASE CALL 1800 666 778 <small>For the cost of a local call (Australia only)</small> or visit www.vintecclub.com
FOR SERVICE or to find the address of your nearest authorised service centre in New Zealand PLEASE CALL 0800 550 020 <small>(New Zealand only)</small>	NEW ZEALAND ELECTROLUX (NZ) Limited 3-5 Niall Burgess Road, Mount Wellington vintec.co.nz	FOR ACCESSORIES PLEASE CALL 0800 550 020 <small>(New Zealand only)</small> or visit www.vintecclub.com




Service and support

In the rare event that your Vintec cabinet does not perform to your satisfaction, contact our dedicated support team:

1800 771 776

concierge@vintecclub.com



Vintec. We are part of the Electrolux Family. To add a touch of professional inspiration to your home, visit electrolux.com.au

Stay in touch and share your user experience by following us:



@vintecclub